



JOWI[®]

Mobile
Storage Systems

- Mobile Racks

How much space should there be between each storey?


Does your customer need a specific gap between each storey?
Or a specific number of storeys?
Or both?

Find out **at a glance:**
which is the perfect JOWI model for each customer's needs.


Mobile Rack B590 and B780 – Summary of storey spacing

16 positions for support tubes,
diameter of support tubes:
23 mm


16 support tubes, storey spacing: 66 mm




8 support tubes, storey spacing: 154 mm




6 support tubes, storey spacing: 243 mm




4 support tubes, storey spacing: 332 mm




4 support tubes, storey spacing: 421 mm



3 support tubes, storey spacing: 510 mm




3 support tubes, storey spacing: 599 mm




Mobile Rack C660, C770, C900 and C1100 – Summary of storey spacing

12 positions for support tubes, diameter of support tubes: 29 mm


12 support tubes, storey spacing: 92 mm




6 support tubes, storey spacing: 213 mm




4 support tubes, storey spacing: 334 mm




3 support tubes, storey spacing: 455 mm



3 support tubes, storey spacing: 576 mm




2 support tubes, storey spacing: 697 mm




Mobile Rack R660, R770, R900 and R1100 – Summary of storey spacing

31 positions for support tubes, diameter of support tubes: 29 mm


31 support tubes, storey spacing: 18 mm




16 support tubes, storey spacing: 66 mm




11 support tubes, storey spacing: 113 mm




8 support tubes, storey spacing: 161 mm



7 support tubes, storey spacing: 208 mm




6 support tubes, storey spacing: 255 mm




Mobile Racks R660, R770, R900, and R1100 – Summary of storey spacing

31 positions for support tubes,
diameter of support tubes:
29 mm


5 support tubes, storey spacing: 303 mm




4 support tubes, storey spacing: 350 mm




4 support tubes, storey spacing: 398 mm




4 support tubes, storey spacing: 445 mm




3 support tubes, storey spacing: 492 mm



3 support tubes, storey spacing: 539 mm




3 support tubes, storey spacing: 588 mm




Mobile Rack Quercus Q640, Q740, Q880, Q1080 and Q1380 – Summary of storey spacing

25 positions for support tubes, diameter of support tubes: 34 mm


25 support tubes, storey spacing: 18 mm




13 support tubes, storey spacing: 70 mm




9 support tubes, storey spacing: 122 mm




7 support tubes, storey spacing: 174 mm



5 support tubes, storey spacing: 226 mm




5 support tubes, storey spacing: 278 mm




Mobile Rack Quercus Q640, Q740, Q880, Q1080 and Q1380 – Summary of storey spacing

25 positions for support tubes, diameter of support tubes: 34 mm


4 support tubes, storey spacing: 330 mm




4 support tubes, storey spacing: 382 mm




3 support tubes, storey spacing: 434 mm




3 support tubes, storey spacing: 486 mm



3 support tubes, storey spacing: 538 mm



3 support tubes, storey spacing: 590 mm





JOWI[®]

Mobile
Storage Systems

Contact us

Do you have a query for the JOWI team?
Give us a call – we're here to help!
Tel. **+43 2743 3844 80**

JOWI Produktions- und Vertriebs-GmbH
Untergrafendorf 70
3071 Böhleimkirchen, Österreich

© JOWI Produktions- und Vertriebs GmbH. Photography: Gerald Lechner; Layout, concept and text: Heavystudios.
Reprinting or reproduction of any kind of the text, images and drawings used in this brochure, even of extracts, may only be carried out with the prior written consent of the publisher. Technical specifications are subject to amendments without notice. Printing and typing errors reserved.